



Particulate Control for Industrial Applications

By David G. Sloat & Paul S. Farber
Sargent & Lundy LLC

Prepared for ICAC – Lake Michigan Air Directors Consortium, Rosemont, Illinois
March 25, 2007

Agenda

- **Brief of Potential Regulations**
 - Industrial MACT & compliance methods
 - Others (INSPS, NAAQS, NSR, etc...)
- **Typical PM Control Devices on Industrial Boilers**
 - Multi-clones
 - ESPs
 - Baghouses
 - Wet Absorber FGD
 - Spray Dryer FGD
- **Potential Upgrades to PM Control**
 - ESP Upgrades
 - Baghouse Retrofits with injection technology (DSI or ACI)
 - Wet and Dry FGD
 - Wet ESPs
- **Summary**

Agenda

- **Brief of Potential Regulations**
 - Industrial MACT & compliance methods
 - Others (INSPS, NAAQS, NSR, etc...)
- **Typical PM Control Devices on Industrial Boilers**
 - Multi-clones
 - ESPs
 - Baghouses
 - Wet Absorber FGD
 - Spray Dryer FGD
- **Potential Upgrades to PM Control**
 - ESP Upgrades
 - Baghouse Retrofits with injection technology (DSI or ACI)
 - Wet and Dry FGD
 - Wet ESPs
- **Summary**

The new Industrial MACT requirements

- 2005 Industrial MACT is currently vacated, reissue in 1-2 months
- Particulate Matter or Total Selected Metals
 - $PM \leq 0.07$ lb/mmBtu or $TSM \leq 0.001$ lb/mmBtu, meet either for compliance
 - PM can be used as a surrogate for TSM compliance
 - New limit could be more restrictive (*0.015 lb/mmBtu to 0.030 lb/mmBtu*)
- Hydrogen Chloride
 - $HCl \leq 0.09$ lb/mmBtu
 - New limit could be more restrictive (*0.02 lb/mmBtu to 0.05 lb/mmBtu*)
- Mercury
 - Hg total ≤ 9 lb/TBtu
 - New limit could be more restrictive (*2 lb/TBtu to 3 lb/TBtu*)

Total Selected Metals include eight metals

- Typically fine particles that have condensed on the surface of a larger particle
- Order of magnitude of 1/100th mass concentration of PM
- Include non-mercury metals
 - Arsenic, Beryllium, Cadmium, Chromium, Lead, Manganese, Nickel, and Selenium
- Selenium is getting attention if it gets into wastewater
- TSM are collect with PM collection equipment

To collect PM and TSM you need very high efficiency devices

- In general, ESPs, baghouses, and wet ESP are likely needed to comply with newer more restrictive PM and TSM values

Hydrogen Chloride (HCl) is captured with wet scrubbing or dry injection

- **Wet Spray Tower Absorbers FGD**
 - Condenses and absorbs HCl, then it can be reacted with an alkali to form a chloride salt
 - Very effective with about 95% capture
 - Can build up in recycle slurry and be corrosive to absorber materials
 - Disposed of as a blowdown from the FGD system and some with the solid FGD waste
- **Spray Dryers (or Circulating Dry Scrubber) FGD with Baghouses**
 - Absorb HCl then it can be reacted with an alkali to form a chloride salt
 - Very effective with about 95% capture
 - Disposed of as part of the dry solid waste product
- **Duct injection**
 - Dry trona, dry hydrated lime, solution of sodium bi carbonate
 - 30% to 90% with high stoichiometry
 - More removal if humidification is used ahead of injection
 - Disposed of as part of the fly ash

Mercury is in flue gas in three species

- PM mercury is small percentage, often $\leq 10\%$
 - Collectable in most PM collectors
- Elemental mercury
 - Hg^0
 - Most difficult to collect
 - Powdered Activated Carbon (PAC) can collect at high efficiency 90% in correct conditions ($T < 400^\circ\text{F}$ and/or $\text{SO}_3 \leq 5 \text{ ppm}$)
- Oxidized mercury (also called ionic)
 - Hg^{+2}
 - Moderately difficult to collect
 - Can be collected in baghouse dust cake at 10% to 60%
 - With PAC at 90%
 - Can be collected in wet absorber at $\approx 90\%$, but only ionic

Agenda

- **Brief of Potential Regulations**
 - Industrial MACT & compliance methods
 - Others (INSPS, NAAQS, NSR, etc...)
- **Typical PM Control Devices on Industrial Boilers**
 - Multi-clones
 - ESPs
 - Baghouses
 - Wet Absorber FGD
 - Spray Dryer FGD
- **Potential Upgrades to PM Control**
 - ESP Upgrades
 - Baghouse Retrofits with injection technology (DSI or ACI)
 - Wet and Dry FGD
 - Wet ESPs
- **Summary**

Many existing PM control devices are not able to meet MACT, (blue cells show where a device may comply)

PM Device	Removal Efficiency		
	PM	HCl	Hg
Multi-clone	75% - 85%	none	minimal
ESP	90% - 99.5%	none	≤ 10%
Baghouse	99.50%	minimal	10% - 60%
Wet Venturi Absorber	65%-85%	moderate	minimal
Wet Spray Tower	minimal	≈ 95%	≈ 90% of ionic
Spray Dry FGD + BH	99.80%	≈ 95%	20% - 70%
Wet ESP	99.50%	minimal	≈ 90% of ionic

Agenda

- **Brief of Potential Regulations**
 - Industrial MACT & compliance methods
 - Others (INSPS, NAAQS, NSR, etc...)
- **Typical PM Control Devices on Industrial Boilers**
 - Multi-clones
 - ESPs
 - Baghouses
 - Wet Absorber FGD
 - Spray Dryer FGD
- **Potential Upgrades to PM Control**
 - ESP Upgrades
 - Baghouse Retrofits with injection technology (DSI or ACI)
 - Wet and Dry FGD
 - Wet ESPs
- **Summary**

Existing PM devices can be upgraded or replaced to meet MACT (green cells indicate upgrades possible)

PM Device	Removal Efficiency		
	PM	HCl	Hg
Multi-clone	75% - 85%	none	minimal
ESP	90% - 99.5%	none	≤ 10%
Baghouse	99.8%	minimal	10% - 60%
Wet Venturi Absorber	65%-85%	moderate	minimal
Wet Spray Tower	99.8% +	≈ 95%	≈ 90% of ionic
Spray Dry FGD + BH	99.8%	≈ 95%	20% to 70%
Wet ESP	99.50%	minimal	≈ 90% of ionic

Improved PM capture in an Electrostatic Precipitators

ESP Upgrades options

- Improve gas flow distribution
- Reduce air in-leakage
- Add modern TR set controls
- Add high frequency TR sets
- Gas conditioning (SO_3 or NH_3)
- Rebuild ESP internals
- Add taller ESP electrodes
- Add a field on end of ESP

ESP Replacements options

- New larger electrode area ESP
- New baghouse to collect all the PM

Helper equipment

- Slip Stream baghouse to treat partial flow and continue using the ESP
- New Polishing baghouse to collect last 5% - 10% of PM
- New polishing Wet ESP

Existing PM devices can be upgraded or replaced to meet MACT (green cells indicate upgrades possible)

PM Device	Removal Efficiency		
	PM	HCl	Hg
Multi-clone	75% - 85%	none	minimal
ESP	90% - 99.5%	none	≤ 10%
Baghouse	99.8%	minimal	10% - 60%
Wet Venturi Absorber	65%-85%	moderate	minimal
Wet Spray Tower	99.8% +	≈ 95%	≈ 90% of ionic
Spray Dry FGD + BH	99.8%	≈ 95%	20% to 70%
Wet ESP	99.50%	minimal	≈ 90% of ionic

To capture HCl, some upgrades are possible

- Dry sorbent injection ahead of the ESP can collect 30% to 50%
- Dry sorbent injection ahead of the baghouse can collect 60% to 90%
- Usually wet or dry FGD is needed

Existing PM devices can be upgraded or replaced to meet MACT (green cells indicate upgrades possible)

PM Device	Removal Efficiency		
	PM	HCl	Hg
Multi-clone	75% - 85%	none	minimal
ESP	90% - 99.5%	none	≤ 10%
Baghouse	99.8%	minimal	10% - 60%
Wet Venturi Absorber	65%-85%	moderate	minimal
Wet Spray Tower	99.8% +	≈ 95%	≈ 90% of ionic
Spray Dry FGD + BH	99.8%	≈ 95%	20% to 70%
Wet ESP	99.50%	minimal	≈ 90% of ionic

To capture Hg, some upgrades are possible

- PAC injection ahead of an ESP can get 30% to 60%
- PAC injection ahead of an baghouse can get $\approx 90\%$ if $\text{SO}_3 \leq 5$ ppm
- PAC injection and DSI ahead of an baghouse can get $\approx 90\%$ if $\text{SO}_3 \geq 5$ ppm
- Fuel additives ahead of a wet spray tower will oxidize more Hg
 - Halogens (Cl & Bromine) can help convert elemental Hg to Ionic Hg
 - Add to fuel and let elemental convert to ionic in boiler
- PAC injection ahead of an ESP/Baghouse ahead of wet spray tower gives excellent removal
- PAC injection ahead of dry FGD gives excellent removal

Agenda

- **Brief of Potential Regulations**
 - Industrial MACT & compliance methods
 - Others (INSPS, NAAQS, NSR, etc...)
- **Typical PM Control Devices on Industrial Boilers**
 - Multi-clones
 - ESPs
 - Baghouses
 - Wet Absorber FGD
 - Spray Dryer FGD
- **Potential Upgrades to PM Control**
 - ESP Upgrades
 - Baghouse Retrofits with injection technology (DSI or ACI)
 - Wet and Dry FGD
 - Wet ESPs
- **Summary**

Summary

- ESPs can be -
 - Upgraded for improved PM capture
 - Retrofit with trona or lime injection for improve HCl capture
 - Retrofit with PAC injection for improve Hg capture
- Baghouses can be -
 - Upgraded with better bags for improved PM capture
 - Retrofit with Trona or lime injection for improve HCl capture
 - Retrofit with spray dryer technology for improve HCl capture
 - Retrofit with PAC injection for improve Hg capture
- Multi-clones are not easily upgraded
- Wet scrubbers are not easily upgraded
- Wet ESPs are not easily upgraded



Particulate Control for Industrial Applications

David G. Sloat

312-269-2784

david.g.sloat@sargentlundy.com

Paul S. Farber

312-269-2261

paul.s.farber@sargentlundy.com